

How to Mount SpyeGrey, SpyeFrost, and SpyeClear Rear Projection Screen Films

To apply these adhesive-backed screens to windows, glass, acrylic or polycarbonate substrates, have the following items ready to use:

- Rear Projection Film
- Spray bottle with water
- Rubber-blade squeegee (soft, Clear Max Blade)
- Dry, soft cloth (preferably microfiber)
- Blue Painters Tape to mark the boundaries of the screen (if smaller than the substrate)

!!NOTE!!

These films do not have a protective outer layer! If your squeegee is too hard, or has dirt on it, you will see scratches on the screen. We recommend a 5-Inch Clear Max Blade (the softer version of a Blue Max Squeegee). Please use caution.

1. Thoroughly clean the glass or plastic substrate of dirt, dust or oils using mild detergent & water mixture, then squeegee the excess soap/water from the substrate. (We recommend a dilution of 48 oz. water to 1 Tablespoon Johnson's Baby Shampoo.)

2. Use the tape to mark the area that the screen will be applied (if the screen is smaller than the substrate.) This can be marked from the opposite side.

3. Peel the release film from the screen half way back and spray the adhesive-side of the screen and the surface of the substrate with water.

4. Place the screen carefully onto the substrate while aligning the edges to the tape.

5. Remove the water and any air bubbles with the squeegee blade by gently squeezing the water from the center of the screen toward the edges.

NOTE: The squeegee may glide more smoothly over the top of the screen if it is also sprayed with water.

6. Repeat Steps 3 to 5 for the other half of the screen.

NOTE: Make sure to peel the release film evenly from both corners to prevent the screen from creasing or folding over on itself.

7. Remove the excess water with a dry, soft cloth.

8. Remove the tape.